

Bluetooth 1次元バーコードリーダー オプションコード

■コードリーダーの設定方法

- 1 コードリーダーをパソコンに接続します。
- 2 下記の[モード選択]から使用したいモードのバーコードをスキャンします。

【モード選択】



データ転送モード

バーコードを読み取った際に、そのデータを接続している機器にリアルタイムで送信します。送信に失敗してもデータは保存されません。



データ保存モード

スキャンしたバーコードを自動的に保存します。統計データの閲覧やデータのアップロードが必要な場合は、[データ転送・削除設定]の設定コードをスキャンしてください。

- 3 本書の中から設定したいバーコードをスキャンしてください。
※【■設定一覧】をご覧ください。

以上でバーコードの設定は完了です。

■設定一覧 *のついているバーコードはデフォルト設定です。

【接続方法】

Bluetooth
HIDモードBluetooth
HID
ペアリングBluetooth
SPPモード

【データ転送・削除設定】

「データ保存モード」の時に使うオプションコードです。
※大量のデータを送信する際は、文字抜けが発生する場合があります。
その場合は「Bluetooth HID転送速度」のコード転送速度を変更すると、改善される場合があります。

保存したデータを全て削除する



全てのデータを転送する



バーコードリーダー内に保存されているデータの総量を確認する



【キーボード配列の設定】

英語*



日本



【音量設定】

OFF



ON*



【データ出力の文字設定】

通常の大文字*



全て大文字



全て小文字

大文字と
小文字を
反転

【Bluetooth HID転送速度】

文字がスムーズに転送できない、文字抜けが発生する場合には転送速度を変更してください

速い



普通*



遅い

かなり
遅い

【Suffix Terminator キャラクタ設定】

Suffix-None



Suffix-Enter*



Suffix-Tab



【スリープモード設定】

操作を停止してから自動的にスリープモード(電源OFF)に入る時間を設定します。

Disable	
今すぐスリープ モードにする	
10秒	
30秒	
1分*	
2分	
5分	
10分	
30分	

【キーボードのON/OFF設定(iOS)】

iOSシステムで仮想キーボードを表示または非表示にする



【コード設定】

Industrial 2 of 5

On*	
Off	
Disable Parity Check*	
Parity Check and Transfer	
Parity Check and Not Transfer*	

Standard 2 of 5

On*	
Off	
Disable Parity Check*	
Parity Check and Transfer	
Parity Check and Not Transfer*	

Interleaved 2 of 5

On*	
Off	
Disable Parity Check*	
Parity Check and Transfer	
Parity Check and Not Transfer*	

Matrix 2 of 5

On*	
Off	
Disable Parity Check*	
Parity Check and Transfer	
Parity Check and Not Transfer*	

Codabar

On*	
Off	
Parity Check and Transfer*	
Parity Check and Not Transfer	
Send Start &end Character*	
Not Send Start &end Character	

Code MSI

On	
Off*	

Code 93

On*	
Off	

Code 39

On*



Off



Disable
Parity Check*



Full ASCII 39*



Standard 39



Parity Check
and Transfer



Parity Check
and Not Transfer



Code 32

On



Off*



UPC-A

On*



Off



Transmit
Leading Digit*



Not Transmit
Leading Digit



EAN-13 に変換する



EAN-13 に変換しない*



Parity Check
and Transfer*



Parity Check
and Not Transfer



UPC-E

On*



Off



UPC-A に変換する



UPC-A に変換しない*



EAN 13

On*



Off



Parity Check
and Transfer*



Parity Check
and Not Transfer



EAN 8

On*



Off



EAN-13 に変換する



EAN-13 に変換しない*



Parity Check
and Transfer*



Parity Check
and Not Transfer



Code 128

On*



Off



Parity Check
and Transfer



Parity Check
and Not Transfer*



GS1 RSS14

On*



Off

