



INDEX: LVD1525(ESCO)

| REF. NO. | DESCRIPTION                        | PART NO.  | QTY |
|----------|------------------------------------|-----------|-----|
| 1        | Cylinder head                      | 101001    | 1   |
| 2        | Cylinder head packing              | 211011    | 1   |
| 3        | Inlet valve seat                   | F011-JP34 | 1   |
| 4        | Exhaust valve seat                 | F021-JP34 | 1   |
| 5        | Inlet & Exhaust valve seat packing | 212004    | 1   |
| 6        | Inlet & Exhaust valve plate        | 125001    | 2   |
| 7        | Inlet & Exhaust spring plate       | 127001    | 2   |
| 8        | Tank feet rubber packing           | 434001-1  | 1   |
| 9        | Pin                                | 126001    | 4   |
| 10       | In six-angle bolt                  | 352087    | 4   |
| 11       | Spring washer                      | 382004    | 4   |
| 12       | Exhaust elbow                      | 151402    | 1   |
| 13       | Exhaust tube assembly              | F030-JP34 | 1   |
| 14       | Valve seat packing                 | 213010    | 1   |
| 15       | Cylinder                           | 201013    | 1   |
| 16       | Piston                             | 203002    | 1   |
| 17       | Compression ring                   | 206002    | 2   |
| 18       | Oil control ring                   | 207002    | 1   |
| 19       | Piston pin                         | 204002    | 1   |
| 20       | Piston pin snap ring               | 205001    | 2   |
| 21       | Cylinder packing                   | 214010    | 1   |
| 22       | Set nut                            | 371005    | 2   |
| 23       | Spring washer                      | 382005    | 2   |
| 24       | Double head screw                  | 358001    | 2   |
| 25       | Crankcase                          | 301001    | 1   |
| 26       | Front cover packing                | 215001    | 1   |
| 27       | Crankshaft                         | 302001    | 1   |
| 28       | Crankcase cover                    | 304002    | 1   |
| 29       | Rod                                | 316001    | 1   |
| 30       | Oil gauge                          | F051-JP34 | 1   |
| 31       | Oil draining plug                  | 360001    | 1   |
| 32       | Motor cover                        | 433001    | 1   |
| 33       | In six-angle bolt                  | 352091    | 9   |
| 34       | Spring washer                      | 382011    | 4   |
| 35       | Air filter                         | F071-JP34 | 1   |
| 36       | Air filter (element only)          | 171002    | 1   |
| 37       | Air flue oil filling assembly      | F064-JP34 | 1   |
| 38       | Motor                              | F04G-JP34 | 1   |
| 39       | Radiation fan                      | 431005    | 1   |
| 40       | Oil gauge packing                  | 217001    | 1   |
| 41       | Air tank                           | 401116-07 | 1   |
| 42       | Rubber handle                      | 435002    | 1   |
| 43       | Plastic washer                     | 384001    | 2   |
| 44       | Tank wheel                         | 402009    | 2   |
| 45       | Tank wheel nut                     | 403002    | 2   |
| 46       | Drain cock                         | 406001    | 1   |
| 47       | Check valve                        | 409007    | 1   |
| 48       | Pressure gauge                     | 411011-1  | 1   |
| 49       | Pressure switch                    | 412012    | 1   |
| 50       | Unloading tube ass'y               | 240096    | 1   |
| 51       | Cable wire                         | 453028    | 1   |
| 52       | Power wire                         | 452050    | 1   |
| 53       | Safety valve                       | 407005-1  | 1   |
| 54       | Quick coupler                      | 447024    | 1   |
| 55       | Unloading elbow                    | 151001    | 1   |
| 56       | Nipple                             | 441001    | 1   |
| 57       | Regulator valve                    | 410030    | 1   |
| 58       | Pressure gauge                     | 411012-1  | 1   |
| 59       | Overload switch                    | 458001    | 1   |
| 60       | Strain relief clip                 | 457002    | 2   |
| 61       | Centrifugal switch                 | 459013    | 1   |
| 62       | Start capacitor                    | 460001    | 1   |
| 63       | Run capacitor                      | 462003    | 1   |
| 64       | Capacitor cover                    | 455014    | 2   |