

露出形スイッチ

片切

EA940CJ-41
CSSH-1 PW

15A / 300V



片切2個

EA940CJ-42
CSS-11 PW

15A / 300V




片切3個

EA940CJ-43
CSS-111 PW

15A / 300V



露出 片切スイッチ
片切 単極 15A-300V
CSSH-1 PW



露出 片切スイッチ
片切 単極 15A-300V
CSS-11 PW

