

Economy Drum Lifter (Part # 240057)

Operating Instructions and Parts Manual

ATTENTION: TO ENSURE SAFE AND EASY USE OF YOUR WESCO DRUM LIFTER, READ THESE INSTRUCTIONS BEFORE USING.

Description

The Wesco Drum Lifter is designed for lifting closed head 55 gallon steel drums. It features a lightweight body and an easy to use lock pin design that holds the drum firmly in place.

This product is distributed by:

Wesco Industrial Products, LLC
1250 Welsh Road
North Wales, PA 19454
Tel: 215-699-7031 Fax: 215-699-3836

Contact the factory for parts information and ordering.
Visit us on the web at www.wescomfg.com

Unpacking

When unpacking the Wesco Product, check carefully for shipping damage and missing parts. If damage has occurred or any parts are missing, file a claim with the delivering carrier within 24 hours and notify the dealer from whom the unit was purchased.

Warranty Repairs

If the unit does not work properly, contact your dealer or the factory (215-699-7031) for units less than 90 days old.

Non-Warranty Service

If units are older than 90 days, repairs can be made easily on site with factory supplied parts.

NOTE: Do not send units to the factory for service without first obtaining a "Return Merchandise Authorization" (RMA) number from the customer service department. We will not be responsible for merchandise returned without proper authorization.

Spare Parts

Item	Part No.	Description	Qty.
1	053814	Frame Weldment	1
2	150545	Eye Shoulder Screw 5/8-11	1
3	150546	Hex Nut 5/8-11	2

General Safety Information

Warning: The Wesco Drum Lifters are intended for specific functions. Please adhere to the following instructions to ensure safe and proper use.

- (1) Maximum capacity - 700 Lbs.
- (2) Do not exceed rated capacity. Injury to persons or property may result from overloading and misuse.
- (3) **Only use on Closed Head 55 Gallon Steel Drums**

Operating Instructions

- (1) Hang unit on lifting device (hoist, etc.).
- (2) Make sure locking arm of lifter is in open position. If arm is not in open position, pull back clamp bar to set lifter arm open.
- (3) Lower unit until it reaches directly under first lip of drum.
- (4) Secure unit to drum by pushing in clamp bar to lock in place.
- (5) Keep hands clear and raise hoist.
- (6) Move carefully to desired location. Lower again until drum is completely back to ground. Pull back clamp bar once again to disengage lifter from drum.

Warning

- DO NOT use on open head steel drums or any type of fiber or plastic drums.
- Be sure that use of the drum lifter is safe with your equipment.
- Keep hands clear of unit when using.
- Align hoist for a straight line pull centered over load. Do not try side pulls.
- Never leave the drum lifter with a load suspended in the air unattended.
- DO NOT transport any loads over people ever.
- DO NOT attempt to repair when a drum is engaged.
- Periodically check for loose or worn hardware; If found replace at once.



Figure 1

LIMITED WARRANTY

WESCO INDUSTRIAL PRODUCTS (WESCO) warrants to the purchaser of this product for a period of ninety (90) days from the date of purchase that this product shall be free of defects in material and/or workmanship, as follows:

1. WESCO will supply, at no charge, new or rebuilt replacements for any part that fails through a defect in material and/or workmanship during the warranty period. To obtain warranty service, you must deliver the product prepaid, to the WESCO factory.

2. This warranty does not cover any product or product part which has been subject to accident, misuse, abuse or negligence. WESCO shall only be liable under this warranty if the product is used the manner intended by the manufacturer as specified in the written instructions furnished with this product.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE PURCHASER. ANY EXPRESS WARRANTY NOT PROVIDED IN THIS WARRANTY DOCUMENT, AND ANY REMEDY FOR BREACH OF CONTRACT THAT, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION OR OPERATION OF LAW, IS HEREBY EXCLUDED AND DISCLAIMED. UNDER NO CIRCUMSTANCES SHALL WESCO BE LIABLE TO PURCHASER OR ANY OTHER PERSON FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY, EXPRESS OR IMPLIED, A BREACH OF CONTRACT OR OTHERWISE. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY LIMITED IN DURATION TO THE DURATION OF THIS LIMITED WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long any implied warranty lasts, so the above limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.