

## 3-LED PAPERWEIGHT MAGNIFIER


2.5 X MAGNIFICATION



### CAUTION !

- (1) Position the batteries in the correct polarity and don't install the batteries of different types, charge levels or capacity together;
- (2) Keep the batteries away from children ! Dispose the batteries properly.

DO NOT dispose the batteries in trash or fire !



- (1) Glass lens
- (2) LED Lighting (3 positions)
- (3) Battery Compartment
- (4) Switch (the silver circle)
- (5) Power switch (ON/OFF)

#### Lighting

Slide the power switch(5) to the position "on", then press of the silver circle(4) to turn on the LED Lighting(2). Pressing again turn the LEDs off. Once the light is turned on and not turned off , it will turn off automatically after 10 minutes.

#### Replacing the Batteries

- (1) Slide the battery compartment cover open and remove used batteries;
- (2) Insert 2x CR2016 button cells, making sure to position according to the indicated polarity;
- (3) Replace the battery compartment cover.

*NOTES: Remove the insulator prior to first use !*